

\*ALL EXTERNAL PIPING MUST BE INDEPENDENTLY SUPPORTED.
\*ONLY BASE FITTINGS TO BE LEFT INSTALLED AT TIME OF SHIPMENT PER SII PROCEDURE.
\*Consult Snyder's Guidelines for Use and Installation prior to delivery.
Available on-line at <a href="http://www.snyderindustriestanks.com/Technical">http://www.snyderindustriestanks.com/Technical</a>

ALL DIMENSIONS ARE IN INCHES, NOMINAL, & SUBJECT TO CHANGE WITHOUT NOTICE. ALL DIMENSIONS ON ROTATIONAL MOLDED PARTS ARE SUBJECT TO A  $\pm$  3% TOLERANCE.